



MANISCALCO®

Australian for Mosaics™



Minnamurra Stone Moldings Usage – Installation – Care & Maintenance August 2011

Recommended Usage

Minnamurra Stone Moldings is a collection of marble and travertine moldings. Since they are natural stones, they can have a shade variation of V-3. There are 4 shapes. They are available in Honed. The beige marble is also available in a Polished texture. Polished surfaces may scratch, use caution when grouting, and common sense when choosing the location for use.

These may be used on interior residential or commercial walls. They can be used on exterior walls in frost free areas. They can be used in wet, including submerged areas as well as steam rooms. Sealing of all natural stone is recommended. Minnamurra Stone Moldings are calcium based stones, so they are susceptible to acids.

Installation Instructions

General

- 1) Make sure this product is inspected and accepted by the end user before installing. No refunds or adjustments of any kind will be made by Maniscalco or your supplier after the product is installed.
- 2) To cut, use a tile wet saw with a diamond blade designed for cutting stone. Pearl, MK, Target, and many other blade manufacturers make blades for stone. Always wear eye protection.

Suggested Installation Method

- 1) Always use a licensed contractor.
- 2) Always confirm in person with the end user / specifier that the product being installed is the correct product before installing.
- 3) Always inspect the product for unintended flaws that are not part of the fashion or style of the product. Do not install defective or damaged product. If there is a question about the quality of the product, contact your supplier before proceeding.
- 4) Make sure the substrate is suitable for tile. Choose and follow the best technique for your project.

Refer to TCNA handbook, page 10 and all pages pertaining to substrate preparation.

And ANSI A108.1B, A108A2.1.8, C1396, C1396M-04

- 5) Make sure crack isolation membranes and water proofing membranes are considered for your type of installation where necessary.

TCNA handbook, page 9, 10

ANSI a118.10, A108.12

Minnamurra Stone Moldings continued

6) Make sure expansion joints and movement joints are considered and used when necessary. Extra soft joints may be required in high heat areas. Use a soft (caulking) joint between the tile and any other material in a continuous installation. Use a soft joint where two different planes come together. Use a soft joint where the tile abuts to plumbing fixtures, cabinets; counter tops, window or door moldings, and bath tubs/shower pans in accordance with the TCNA handbook.

TCNA handbook, page 8, 9, 68, 69, and EJ171-05

7) Use a modified thin-set mortar that meets or exceeds ANSI 118.4 Follow the manufacturer's instructions.

8) Use the correct size notch trowel depending on the size of the product and your desired results. A 5/32" x 5/32" V-notched trowel is most appropriate. Make sure you achieve full contact between the back of the tile and the thin-set.

9) Allow the thin-set to cure according to the manufacturer's instructions.

10) Pre-sealing is suggested and may aid in clean up. However, do not allow the sealer to saturate the edges of the stone pieces preventing the grout from sticking to the edges.

11) Sanded or non-sanded grout may be used.

12) Read and follow all manufacturers' instructions on the grout.

13) Buff and cure the grout according to the grout manufacturer's instructions. Once the grout is cured, seal the Moldings and grout.

The installer is responsible for choosing and using the correct installation practices to achieve an acceptable finished product. Please refer to the TCNA hand book regularly, it is revised each year and techniques can change. Our goal is to have trouble-free installations that can be enjoyed for a lifetime. Use constitutes acceptance, there will be no credits, refunds, cash settlements, and etc. made after the product is installed regardless of the circumstances. The TCNA website is www.tileusa.com.

Care & Maintenance

Regular cleaning with a mild bathroom cleaner or neutral stone cleaner and a soft cloth or sponge according to the manufacturer of the cleaner is recommended. Buff dry with a soft cloth. Do not use acids, corrosive, or abrasive cleaners.